

PC requirements Fusyo	Minimum	Recommended
<i>CPU Type</i>	<p>All computers with following processors:</p> <ul style="list-style-type: none"> - INTEL Core i5 (or higher) minimum 2 Ghz frequency - AMD A10 (or higher) minimum 2 Ghz freq¹ 	<p>All the computer with following processors:</p> <ul style="list-style-type: none"> - INTEL Core i5 « génération 8 » (or higher) minimum 2 Ghz - AMD Ryzen« génération3 » (or higher) minimum 2Ghz¹
	<ul style="list-style-type: none"> - Mac IOS is not compatible - Computer All-in-one / AIO are not recommended - Tablets are not compatible - micro-Computer and Stick PC are not recommended <p>If you already have a PC or for any advice Please Contact us</p>	
<i>OS</i>	Windows 8.1, 10, 11 (32 or 64 bits) ² Windows 10 S not supported	
<i>RAM</i>	4 Go	8 Go
<i>HARD DRIVE</i>	128 Go	256 Go
<i>Screen resolution</i>	1366x768 pixels	1920x1080 pixels
<i>USB ports</i>	Minimum 2 USB ports on PC (1 USB port dedicated only to the plate) USB C Port compatible with adapter only	
<i>Webcam option</i>	<ul style="list-style-type: none"> - webcam running at 30 frames per second - 1 graphic board dedicated to the webcam - 1 dedicated USB port to the camera 	
<i>Back up</i>	External USB hard drive	

An environment overloaded with wifi networks can alter the wireless connection of your pressure device.

This document is indicative and does not guarantee the full compatibility of your PC with your pressure device.

1 AMD Ryzen CPU : USB wire maximum 3 meters

2 Fusyo with external power supply (old generation) run only in 32 bits